


VINYL DECAL Application Instructions

40 VISUALS



Glass & interior painted surfaces must be cleaned using mild soap and water, or Windex. Use lint free cloth or industrial paper towels to dry surface. Temperature of glass must



be moderate –between approx. **40° F and 55° F**. Freshly painted walls must be dry one week prior to application.



Cold weather, apply in the late afternoon when windows are warmest. Applying when too cold may affect adhesion of material.



Hot weather, apply in the early morning when windows are coolest. Applying when too hot can cause stretching during installation.

1 POSITION DECAL. Use small strips of masking tape to position lettering properly in the intended space.

2 REMOVE BACKING/ PRESS DOWN DECAL. Using the provided felt squeegee or your hand lightly press the material in place as you remove the white backing paper. Leave the top layer of transfer masking intact. Once the white backing paper has been completely removed. Apply pressure back and forth over entire graphic to ensure a strong bond with the wall or window.

3 PEEL OFF MASKING. Slowly remove the transfer masking by starting in one corner and peeling toward the opposite corner at a 45° angle until completely removed.

4 FINISHED! All that should remain at this point is the vinyl graphic!

? Please give us a call, [800-962-3119](tel:800-962-3119)

